

Positioning belts are used by people who need additional support in the wheelchair or seating system. The belts can be used either as a complete set or in various combinations, according to user's needs.



## **Six-point Shoulder Strap/Chest Strap combination**

The combined strap provides upper body support by keeping the shoulders and upper chest in a more upright position. The strap can be easily opened using buckles and it can be adjusted to fit around the user's trunk.

Available in three sizes, from 10" to 18".



## **Thoracic Strap**

The chest strap provides upper body support by keeping the shoulders and upper chest in a more upright position. The strap can be easily opened using buckles and it can be adjusted to fit around the user's trunk.

Available in five sizes, from 10" to 18".



## **Four-Point Pelvic Strap**

The Four Point Pelvic Strap offers improved resistance to movement and superior stability. The secondary attachment straps reduce the pelvic belt twisting. The belt holds the pelvis in a good position when the person has a lot of movement.

Available in three sizes, from 10" to 18".

### **Two-Point Pelvic Strap**



The Two Point Pelvic Strap improves the stabilization of the pelvis in a good seating position in the wheelchair or the seating unit. The strap tension can be adjusted easily according to the user's requirements.

Available in three sizes, from 10" to 18".

### **Foot Strap**



The Foot Strap helps to stabilize the user's foot while allowing controlled movement. The strap improves comfort and tolerance for positioning.

Available in three sizes, from 10" to 18".