


'Flying Start' Racing Wheelchair





Assembly Manual


August 2013

Rear Wheel Assembly













Front Wheel Assembly









Footplate Assembly and Adjustment
























3


Footplate Assembly and Adjustment




Footplate Angle options: A, B, C and D (all with forward/back adjustment, as shown)




Steering System Alignment




Steering System Alignment





Steering System Alignment







Steering Adjustment






Rotate the 'compensator' bolts (above) to adjust for straight-line travel (as shown below, left) and to adjust for curved travel on a race track bend (as shown below, right)











Anti-Tip Bar Assembly and Adjustment







Anti-Tip Bar in correct downward position to stop the wheelchair tipping back

Anti-Tip Bar in upward position, for storing the the Bar when not in use

Attaching the Anti-Tip Bar in place, using the spring-pin



Removing the Anti-Tip Bar, using the spring-pin






Upholstery Assembly and Adjustment - 2 Positions

Sitting Position

Backrest Panel set-up







View of backrest straps attached to seat rail



Kneeling Panel set-up (angle of pad is altered by adjusting the straps)



Backrest and Kneeling panel in place



Backrest and Kneeling panel in place

